

UBICACIÓN: Honduras,
Francisco Morazan,
Municipio de Valle de Ángeles, Sitio
"Liquidambal".




Tabla de rumbos y distancias

Linea	Longitud(m)	Rumbo
1-2	47.59	N25° 00' 48.77"E
2-3	63.24	N51° 15' 03.27"E
3-4	48.05	S25° 47' 11.17"E
4-5	28.41	S21° 57' 05.77"E
5-6	21.69	S30° 18' 25.97"E
6-7	22.51	S78° 52' 00.33"E
7-8	28.16	S58° 52' 32.60"E
8-9	16.78	S60° 04' 38.19"E
9-10	15.47	S12° 07' 58.97"E
10-11	13.16	S0° 18' 32.48"W
11-12	114.16	S18° 56' 35.91"W
12-13	12.07	S17° 51' 57.13"W
13-14	89.26	S0° 32' 04.87"W
14-15	98.10	S17° 52' 05.16"W
15-16	69.84	S31° 51' 41.59"W
16-17	94.88	S39° 17' 25.99"W
17-18	117.07	S77° 00' 53.36"W
18-19	41.70	N80° 29' 45.51"W
19-20	70.16	N44° 04' 33.77"W
21-21	41.72	N47° 04' 35.51"E
21-22	31.20	N31° 44' 26.41"E
22-23	32.01	N55° 04' 10.97"E
23-24	51.89	N25° 39' 08.76"E
24-25	40.09	N39° 45' 20.87"E
25-26	49.80	N40° 04' 16.22"E
26-27	21.03	N47° 16' 34.08"E
27-28	23.94	N32° 26' 05.46"E
28-29	39.12	N28° 37' 54.66"E
29-30	15.47	N30° 19' 48.00"E
30-31	32.54	N0° 01' 03.38"E
31-32	25.33	N25° 16' 11.98"W
32-33	30.50	N60° 30' 08.47"W
33-34	32.93	N2° 46' 58.18"E
34-35	40.02	N6° 13' 15.57"E
35-36	21.90	N14° 49' 54.61"E
36-37	25.22	N32° 08' 33.45"E
37-1	8.27	N6° 53' 07.43"E

Area=97,611.32m²
=14.000rs2=14mnz